Python Line Series - Conveyor Belt Alignment Switches



APPLICATION:

Conveyor Belt Alignment switches are mounted on sections of plant conveyors to protect against excessive belt drift due to an unintentional movement. They can be fitted at appropriate points along the conveyor length to ensure that should the belt position drift, the roller arm of the switch will move to a pre-determined position and cause activation of a control circuit.

All switches conform to European Standard IEC 60947-5-1 and provide positively operated contacts at the point of tripping. They can be used to satisfy the requirements of EN 620 with regard to conveyor control hazards caused by shifting of the belt position during running. They are available in different roller diameters to provide heavy duty performance and long life.

OPERATION:


The steel roller of the switch is placed near to the running edge of the conveyor belt such that deflection of the roller and arm will cause activation "tripping" of the internal contacts of the switch. Adjustment of the tripping angles and necessary activation torque is provided by the switch.

INSTALLATION GUIDE:

- 1. Installation of all switch systems must be in accordance with a risk assessment for the individual application. Installation must only be carried out by competent personnel and in accordance with these instructions.
- M5 mounting bolts must be used to fix the switches. Tightening torque for mounting bolts to ensure reliable fixing is 4 Nm. 2. Tightening torque for the lid screws, conduit entry plugs and cable glands must be 1.5 Nm to ensure IP seal. Only use the correct size gland for the conduit entry and cable outside diameter.
- 3. The position of the roller must be chosen to ensure that in normal use the belt does not touch the roller, but that should the belt move beyond its normal guides it will make contact with the roller. After selecting the correct mounting position, the switching points of the internal contact blocks can be finely adjusted via internal cams.

There are 2 internal contact blocks one to provide a "STOP" signal the other to provide a "WARNING" signal. The blocks offer NC and NO circuits.

Final Adjustment of contact block action:



Operational torque can be increased or decreased by turning the adjustment

www.idemsafety.com

Python Line Series - Conveyor Belt Alignment Switches


MAINTENANCE:

Every month:

Check correct operation at all switch locations along all coverage length. Check for nominal warning and trip angle, re-set if necessary.

Every 6 months:

Isolate power and remove cover. Check screw terminal tightness and check for signs of moisture ingress. Never attempt to repair any switch.



Medium Duty 1.8Nm to 2.8Nm

Heavy Duty 3.0Nm to 5.0Nm

30 degrees

65 degrees

Operating Torque range (adjustable)

Maximum tilt angle (mounting angle)

Maximum Deflection

209

Python Line Series - Conveyor Belt Alignment Switches

MEDIUM DUTY - STAINLESS STEEL BELT SWITCH 35mm x 120mm ROLLER ORDERING:



SALES NUMBER	DESCRIPTION	MEDIUM DUTY BELT ALIGNMENT SWITCH		
	ALL VERSIONS ARE 2NC 2NO	Operating Torque	WARNING	STOP
501001	Belt Switch 35 x 120mm Roller M20			
501002	Belt Switch 35 x 120mm Roller 1/2" NPT			
501003A	Belt Switch 35 x 120mm Roller M20 24V LED	1.8Nm to 2.8Nm	10-18 degrees	15-35 degrees
501003B	Belt Switch 35 x 120mm Roller M20 110V LED			
501003C	Belt Switch 35 x 120mm Roller M20 230V LED	(Factory set	(Factory set at	(Factory set at
501004A	Belt Switch 35 x 120mm Roller 1/2" NPT 24V LED	to 1.8Nm)	14 degrees)	25 degrees)
501004B	Belt Switch 35 x 120mm Roller 1/2" NPT 110V LED			
501004C	Belt Switch 35 x 120mm Roller 1/2" NPT 230V LED			
501021	Belt Switch 35 x 120mm Roller EX 3m pre-wired			

HEAVY DUTY - STAINLESS STEEL BELT SWITCH 35mm x 230mm ROLLER ORDERING:

SALES NUMBER	DESCRIPTION	MEDIUM DUTY BELT ALIGNMENT SWITCH		
	ALL VERSIONS ARE 2NC 2NO	Operating Torque	WARNING	STOP
501005	Belt Switch 35 x 230mm Roller M20			
501006	Belt Switch 35 x 230mm Roller 1/2" NPT			
501007A	Belt Switch 35 x 230mm Roller M20 24V LED	3.0Nm to 5.0Nm	10-18 degrees	15-35 degrees
501007B	Belt Switch 35 x 230mm Roller M20 110V LED			
501007C	Belt Switch 35 x 230mm Roller M20 230V LED	(Factory set	(Factory set at	(Factory set at
501008A	Belt Switch 35 x 230mm Roller 1/2" NPT 24V LED	to 3.0Nm)	14 degrees)	25 degrees)
501008B	Belt Switch 35 x 230mm Roller 1/2" NPT 110V LED			
501008C	Belt Switch 35 x 230mm Roller 1/2" NPT 230V LED			
501051	Belt Switch 35 x 230mm Roller EX 3m pre-wired			






SALES NUMBER	DESCRIPTION	MEDIUM DUTY BELT ALIGNMENT SWITCH		
	ALL VERSIONS ARE 2NC 2NO	Operating Torque	WARNING	STOP
501009	Belt Switch 50 x 170mm Roller M20	3.0Nm to 5.0Nm	10-18 degrees	15-35 degrees
501010	Belt Switch 50 x 170mm Roller 1/2" NPT			
501011A	Belt Switch 50 x 170mm Roller M20 24V LED			
501011B	Belt Switch 50 x 170mm Roller M20 110V LED			
501011C	Belt Switch 50 x 170mm Roller M20 230V LED	(Factory set	(Factory set at	(Factory set at
501012A	Belt Switch 50 x 170mm Roller 1/2" NPT 24V LED	to 3.0Nm)	14 degrees)	25 degrees)
501012B	Belt Switch 50 x 170mm Roller 1/2" NPT 110V LED			
501012C	Belt Switch 50 x 170mm Roller 1/2" NPT 230V LED			
501091	Belt Switch 50 x 170mm Roller EX 3m pre-wired			

<u>www.idemsafety.com</u>


SECTION 22

Python Line Series - Conveyor Belt Alignment Switches


MEDIUM DUTY - STAINLESS STEEL BELT SWITCH 35mm x 120mm DIMENSIONS (mm):



HEAVY DUTY - STAINLESS STEEL BELT SWITCH 35mm x 230mm DIMENSIONS (mm):



HEAVY DUTY - STAINLESS STEEL BELT SWITCH 50mm x 170mm DIMENSIONS (mm):



For all IDEM switches the normally closed (NC) circuits are closed when the system is tensioned correctly and the switch has been reset.